


Lyttelton Port - Standard Passage Plan Pack



Issued: 19/02/2024

Welcome to Lyttelton Port. The dual Purpose of this document is to:

1. Provide advance information to Masters of vessels visiting to Lyttelton Port in relation to;
 - a. key port information
 - b. the Master Pilot Exchange (MPX) Document
 - c. the standard passage plans that LPC Pilots work to
2. Provide LPC Pilots with a standardised and agreed planning framework upon which the Master Pilot Exchange (MPX) can be based.

In all instances the MPX will be conducted prior to entry to or departure from the Port, and will take into consideration the conditions on the day. The purpose of the MPX is to create a 'shared mental model' and subsequent agreement between the Pilot and the Master in advance of the vessel transit.

If agreement is not able to be reached, then the Pilotage will not proceed.

Section 1: Port Information

Anchorage

The main anchorage for vessels waiting for a berth is a combined general anchorage and quarantine anchorage situated in position: Latitude 43° 33.0' South, Longitude 172° 50.0' East (approximately 2.5 nautical miles bearing 026 degrees (True) from Godley Head).

Communication

A 24/7 visual and listening watch is maintained by Lyttelton Harbour Radio. Communication is available on VHF channels 16,12 and 63.

Port Navigation:

The pilot station BRAVO is situated two miles ENE from Godley Head (Latitude: 43° 34.91' South, Longitude: 172° 51.22' East).

The pilot station ALPHA is typically used in heavy weather/sea conditions (Latitude: 43° 34.22' South, Longitude: 172° 52.93' East).

Pilotage

Pilotage is compulsory for all vessels over 500GT or over 40m LOA, unless exemption is obtained from Maritime New Zealand.

LPC pilots use a Navicom Dynamic Harbour Pilot Position (PPU) monitoring system to enable highly accurate monitoring when manoeuvring large vessels in and out of the harbour.

The Master Pilot Exchange (MPX) process will result in an agreed plan for the safe transit of the vessel into or out of Lyttelton Port.

Wind

In addition to specific vessel type and berth location wind limits, Lyttelton Port has an overall wind limit of 35 knots (sustained) beyond which arrivals into the Port will be suspended. Strong North Westerly and South Westerly winds are identified as a specific hazards for visiting vessels, and these hazards are identified within the generic plans contained in this document. The Duty Pilot will advise on specific wind limits.

Towage

Berthing is aided by two Azimuth Stern Drive tugs: *Blackadder*, with a bollard pull of 62.5 tonnes, and *Piaka*, with a bollard pull of 70 tonnes.

DUKC®

LPC operates a Dynamic Under Keel Clearance (DUKC®) system, aiding in the safe transit of vessels in and out of port.

The DUKC system is used to accurately predict a particular vessel's under keel clearance (DUKC®) based on the vessel's dimensions and stability, the prevailing environmental conditions, predicted vessel speeds and a detailed profile of the Lyttelton Harbour approach channel.

***Notice:** These plans presented in this document are indicative only. LPC accepts no liability from the reliance of these plans. The MPX process will result in an agreed plan for the safe transit of the vessel into or out of Lyttelton Port.*

Key Port Information

Recommended routes between the designated Pilot Boarding station and the selected berth or anchorage are shown below. These plans are indicative and can be deviated from only at the discretion of the Master and/or Pilot. LPC accepts no liability from the reliance of these plans.

Pilot Boarding Station to Cashin Quay						
Name	Latitude	Longitude	Turning Radius (M)	Legline Bearing	Legline Speed (kts)	Legline X Track (M)
PS Alpha	43°34.22'S	172°52.93'E	500	241	12	50
PS Bravo	43° 34.91'S	172° 51.22'E	500	241	12	50
Camp Bay	43° 36.255'S	172° 47.8187'E	500	261	8	50
Cashin Quay	43° 36.75'S	172° 43.7'E				
Pilot Boarding Station to Inner Harbour						
PS Alpha	43°34.22'S	172°52.93'E	500	241	12	50
PS Bravo	43° 34.91'S	172° 51.22'E	500	241	12	50
Camp Bay	43° 36.255'S	172° 47.8187'E	500	261	8	50
Shag Reef	43°36.834'S	172°43.0286'E	300	005	4	30
Inner Harbour	43°36.4772'S	172°43.0286'E				

Section 2: MPX and Berth Guide

MPX – LPC Master Pilot Exchange Form

LPC uses an electronic MPX system (eMPX) as the primary document for conducting the MPX.

On occasion LPC Pilots will use the hard copy MPS (as shown below). A PDF download of the hard copy LPC MPX is available from the following web link.


<http://www.lpc.co.nz/wp-content/uploads/2015/06/LPC-Pilotage-Passage-Plan.pdf>

HW	TIME	HEIGHT	<input type="checkbox"/> UKC	UKC		DRY DOCK	FLOOR 137.14M	TOP 147M	ENTRANCE 18.8M W	MAX DRAFT 5.1M	HDG 260T
LW	TIME	HEIGHT	<input type="checkbox"/> DUIC	HARBOUR	INNER HARBOUR						
FLOW			EBB / FLOOD / SLACK			TIDE HEIGHT		DEPTH AT CD			
WIND			WEATHER: PRESENT			TOTAL DEPTH		DRAFT			
WIND			WEATHER: PREDICTED			UKC STATIC		UKC DYNAMIC (1)			
REMARKS						UKC DYNAMIC (2)		SWELL (if any)			

FOR MASTER / PILOT EXCHANGE DURING PASSAGE PLANNING. REFER TO CHART NZ 4321 FOR NAVIGATION.

LYTTELTON PORT PILOTAGE PASSAGE PLAN	
Lyttelton Port listens continuously on VHF 12 / 16. VHF 02 is a working channel for Pilots and Tugs. The bridge team is reminded of its duty to maintain an accurate check on the vessel's position as laid down in the ISM Code, STCW Convention, IMO Regulations & ICS Bridge Procedures Guide. The bridge team is requested to monitor the pilots actions at all times, and to challenge the pilot if in doubt of the planned passage or ship's progress. Smoke free bridge.	
VESSEL: Date: _____ Movement: <input type="checkbox"/> In <input type="checkbox"/> Out <input type="checkbox"/> Shift Channels: VHF 02—12—16 Pilot: _____ Berth: _____ Actual Depth: <input type="checkbox"/> P52 <input type="checkbox"/> S52 Ladder: <input type="checkbox"/> P <input type="checkbox"/> S Ladder Height: _____ Pilot Card: <input type="checkbox"/> Yes <input type="checkbox"/> No Main Engine(s) _____ Tested _____ Thrusters: <input type="checkbox"/> Bow KW / HP = _____ <input type="checkbox"/> Stern KW / HP = _____ Tested _____ Anchors Clear: <input type="checkbox"/> P <input type="checkbox"/> S Use <input type="checkbox"/> Gyro Error <input type="checkbox"/> Bridge Equipment OK TUGS: Backscatter 62t <input type="checkbox"/> F <input type="checkbox"/> A 1st/Last Line _____ F _____ A _____ Ploks 70t <input type="checkbox"/> F <input type="checkbox"/> A Lines _____ F _____ A _____ TUGS SWL of ships bits <input type="checkbox"/> F <input type="checkbox"/> A Tugs use tug line. When letting go tug lower line slowly using a turn on mooning bit (illustrated below)	
The Pilot and Master certify that the pilotage plan has been discussed with the Bridge Team Pilot _____ Date / Time _____ Master _____ Date / Time _____	
Version 3 1/12/2019 REFER TO CHART NZ4321	

FOR MASTER / PILOT EXCHANGE DURING PASSAGE PLANNING—NOT TO BE USED FOR NAVIGATION



FOR MASTER / PILOT EXCHANGE DURING PASSAGE PLANNING—NOT TO BE USED FOR NAVIGATION

LYTTELTON PORT PILOTAGE PASSAGE PLAN



Lyttelton Port listens continuously on VHF 12 / 16. VHF 02 is a working channel for Pilots and Tugs.

The bridge team is reminded of its duty to maintain an accurate check on the vessel's position as laid down in the ISM Code, STCW Convention, IMO Regulations & ICS Bridge Procedures Guide.

The bridge team is requested to monitor the pilots actions at all times, and to challenge the pilot if in doubt of the planned passage or ship's progress. Smoke free bridge.


VESSEL:			
Date:		Movement:	<input type="checkbox"/> In <input type="checkbox"/> Out <input type="checkbox"/> Shift
Channels:	VHF 02—12—16	Pilot:	
Berth:		Actual Depth:	<input type="checkbox"/> PS2 <input type="checkbox"/> SS2
Ladder:	<input type="checkbox"/> P <input type="checkbox"/> S	Ladder Height:	
Pilot Card:	<input type="checkbox"/> Yes <input type="checkbox"/> No	Main Engine(s)	Tested
Thrusters:	<input type="checkbox"/> Bow KW / HP =	<input type="checkbox"/> Stern KW / HP =	Tested
Anchors Clear:	<input type="checkbox"/> P <input type="checkbox"/> S	Use	<input type="checkbox"/> Gyro Error <input type="checkbox"/> Bridge Equipment OK
TUGS:	On departure, engine not to be tested until Pilot on Bridge.		
Blackadder	62t bp <input type="checkbox"/> F <input type="checkbox"/> A	1st/Last Line	F A
Piaka	70t bp <input type="checkbox"/> F <input type="checkbox"/> A	Lines	F A

TUGS SWL of ship's bitts <input type="checkbox"/> F <input type="checkbox"/> A 	Tugs use tugs line. When letting go tug lower line slowly using a turn on mooring bitt (illustrated below)
--	--

The Pilot and Master certify that the pilotage plan has been discussed with the Bridge Team

Pilot _____ Date / Time _____

Master _____ Date / Time _____




FOR MASTER / PILOT EXCHANGE DURING PASSAGE PLANNING.

REFER TO CHART NZ 6321 FOR NAVIGATION


LYTTTELTON PORT DRY DOCK PASSAGE PLAN

Issued: 19/02/2024
File: DRY - EMPX



VESSEL:	
Date:	<input type="checkbox"/> Docking <input type="checkbox"/> Undocking
Contact:	
Stability Data:	
Engine:	<input type="checkbox"/> Available <input type="checkbox"/> Not available
Bow thruster:	<input type="checkbox"/> Available <input type="checkbox"/> Not available
Tugs Required?	<input type="checkbox"/> Piaka <input type="checkbox"/> Blackadder
LPC Rescue?	<input type="checkbox"/> Yes <input type="checkbox"/> No
Double Docking?	<input type="checkbox"/> Yes <input type="checkbox"/> No If yes, use 2 tugs to speed up
Hull Protrusions?	_____
Vessel PS2 at berth?	<input type="checkbox"/> Yes <input type="checkbox"/> No If yes; tug to change sides
Winches Operable?	<input type="checkbox"/> Yes <input type="checkbox"/> No
Use dock capstan?	<input type="checkbox"/> Yes <input type="checkbox"/> No
Owners rep on board?	<input type="checkbox"/> Yes <input type="checkbox"/> No Sign: _____
Communication with crew	<input type="checkbox"/> Yes <input type="checkbox"/> No
Starks staff?	<input type="checkbox"/> Yes <input type="checkbox"/> No
Discuss with Dock master	<input type="checkbox"/> Yes <input type="checkbox"/> No
All in agreement with plan?	<input type="checkbox"/> Yes <input type="checkbox"/> No


LYTTELTON PORT DRY DOCK PASSAGE PLAN



Tug Arrangement




Mooring Arrangement



COMMENTS

Maximum permissible wind for docking / Undocking is 25 Knots from any direction.




Section 3: Standard Passage Plans


Symbol Key




Speed - expressed in knots



Wheel over position – target speed and Rate of Turn



Pilot Boarding Station



Heading



Potential wind hazard




General Hazard




Key information




Abort swing area




Arrival: Pilot Station to Camp Bay - Out of Channel - Draft determined by Pilot to maximum of 10.0m




Departure: Camp Bay to Sea






Arrival: Camp Bay to Breakwater




Leading Out of Vessels <105m LOA & <7.5m Draft


May be used when sea conditions pose a risk to Pilot Disembarkation at Spar Buoy No.3




Arrival: Breakwater to CQ1 PSTQ




Arrival: Breakwater to CQ1 SSTQ




Arrival: Breakwater to CQ-West PSTQ




Arrival: Breakwater to CQ-East PSTQ







Arrival: Breakwater to CQ-West SSTQ



Arrival: Breakwater to Cruise Berth PSTQ – Bow to Stbd




Arrival: Breakwater to Cruise Berth AZI PSTQ – Bow to Stbd




Not to be used for navigation – refer to Chart NZ6321


Arrival: Breakwater to Cruise Berth PSTQ – Bow to Port




Arrival: Breakwater to Cruise Berth SSTQ (non Cruise)



Departure: Cruise Berth PSTQ to Breakwater




Departure: Cruise Berth PSTQ to Breakwater – – Strong S'ly Wind




5 - 7

Not to be used for navigation – refer to Chart NZ6321


Departure: Cruise Berth SSTQ to Breakwater (Non Cruise)




Cruise Berth Arrival – Mooring Operation with Lines Boats




Departure: CQ1 SSTQ to Breakwater




Departure: CQ1 PSTQ to Breakwater




Departure: CQ1 SSTQ to Breakwater – Strong S'yly Wind




Departure: CQ-East PSTQ to Breakwater




Departure: CQ-East PSTQ to Breakwater – Strong SW'ly Wind




Departure: CQ-East SSTQ to Breakwater (Bow to Stbd)




Departure: CQ-West PSTQ to Breakwater – Strong SW'y Wind




Departure: CQ-West SSTQ to Breakwater (Bow to Stbd)




Departure: CQ-West SSTQ to Breakwater (Bow to Port)




Arrival: Breakwater to 2East SSTQ




Arrival: Breakwater to 2East PSTQ




Arrival: Breakwater to 7East SSTQ




Arrival: Breakwater to 7East PSTQ




Arrival: Breakwater to 3West SSTQ




Arrival: Breakwater to 3West PSTQ



Arrival: Breakwater to Oil Berth SSTQ



Departure: 2East SSTQ to Breakwater



Departure: 2East SSTQ to Breakwater


Cruise Ships: attention to speed passing through entrance to make turn onto outer leads.

ALTERNATE:

- 1) use engines and thrusters to move v/l more to west at slow speed
- 2) V/I heading reduces angle of turn onto leads

Due to narrow inner harbour entrance:


- PAX >220m: Max arrival wind limit 15kn gusting 20kn
- PAX >220m: Max departure wind limit 20kn
- PAX >=228m: Max departure wind limit 15kn




Not to be used for navigation – refer to Chart NZ6321

Course Vector 3M
Depth in Metres


Departure: 2East PSTQ to Breakwater




Departure: 7East SSTQ to Breakwater




Departure: 7East PSTQ to Breakwater



Departure: 3West SSTQ to Breakwater




Departure: 3West PSTQ to Breakwater




Not to be used for navigation – refer to Chart NZ6321

Course Vector 3M
Depth in Metres


Departure: Oil Berth SSTQ to Breakwater




Shift: Dry Dock to 3West PSTQ



Arrival: Breakwater to Dry Dock



Shift: CQ1 SSTQ to 7E PSTQ




Hazard: Berths subject to strong off-shore winds in North Westerly conditions

Hazard: Coal Loader


W/O Pos'n:
260° to 006°
3.5 - 4.5kts
ROT 15-20°

Adjust W/O
position to allow
for strong SW'ly or
NE'ly to E'ly wind

Not to be used for navigation – refer to Chart NZ6321




Shift: 7E SSTQ to CQ1 PSTQ




Not to be used for navigation – refer to Chart NZ6321

Shift: 7E PSTQ to CQ1 PSTQ




Shift: 7E PSTQ to CQE SSTQ




Not to be used for navigation – refer to Chart NZ6321

Shift: CQE SSTQ to 7E SSTQ




Not to be used for navigation – refer to Chart NZ6321


Shift: CQE SSTQ to 7E PSTQ




Not to be used for navigation – refer to Chart NZ6321



Shift: CQE PSTQ to 7E SSTQ



Shift OB SSTQ to 3E PSTQ



Shift OB SSTQ to 3E SSTQ

